



USER GUIDE FOR Splash Deck Pool Platform

MODEL 001 - 002 Last Revised: July 2017

DETAILS & SAFE USE

- Each pool platform is made from moulded PVC material, which has lifelong warranty and each platform is covered with PVC polyester mesh on the top and sides of the platform.
- SPLASHDECK has been independently tested to assess for weight loading and build quality by a leading testing and certification body under The General Product Safety Directive 2001 I 95/EC.
- All materials are waterproof and the platforms have been fully load and chemical tested for use in the specific environment it is intended for.
- Mesh on the sides of the pool platform prevents anyone swimming under or through it.
- Each platform has been designed to sink easily and has rubber feet to limit movement when in the water and prevent damage to delicate swimming pool tiles.
- The water flow system, by way of sinker holes for water to quickly flow through and within the frame of the platform, also means that the pool can be lifted in and out of the pool, following safe use guidance.
- Splash Deck Standard (Small platform) weighs 14kg (124cm x 65cm x 50cm)
- Splash Deck Large (Large platform) weighs 18kg (184cm x 65cm x 50cm)
- Every platform has been tested to withstand a massive 600kg load weight and are designed to allow for 3 4 (standard) or 5 6 children (large) in mind.
- We advise that correct manual handling assessment is reviewed and that 2 people attend to the large platform when lifting in and out of the water.
- Please ensure that a risk assessment for lifting and platform use is in place dependent on your specific pool surrounds and design.
- The platforms are intended for use within a swimming teaching environment. As such, and when in use, please ensure that a suitably responsible person is in attendance at all times.
- Please ensure that students do not jump on the platform when in the water.
- The platform is not intended as a diving platform and should only be used in the water.
- Please ensure all students are aware of the pool depths when not standing on the platform.

STORAGE & MAINTENANCE

- Storage and care of the platform is important. When not in use, please store platform in area where the platform can dry out.
- The platform should always be removed from the swimming pool when not in use.
- Keep the platform away from sharp objects that could pierce or tear the mesh.
- Wash the platform regularly with cold or cool water and use a non-abrasive cloth or towel.
- Refrain from sliding against tiled or abrasive surfaces that could damage the undercarriage.
- Protective corners are added to every platform. Even so, do not drag the platform along
 the floor as this will reduce longevity of the platform may damage the rubber feet and/or
 rip the mesh.
- The platform should be regularly inspected for damage that may limit the safe use of the product.
- We advise that fixings be inspected at least once a month and tightened if required for continued care.
- A further set of rubber feet are provided along with every platform. Additional packs can be ordered at a cost of £15.00.
- We advise against storing the platforms on top of each other.
- Please keep the platforms feet down when outside of the water.
- Platform mesh can be replaced if required. Please contact us for more information.

CONTACT DETAILS





